

# **TROUBLE SHOOTING AQUAHEAT 5RO-S**



#### NO POWER TO THE DISPLAY:

Power point is faulty. Test power point with a known working appliance. If the power point is operational, check the controller with another power point and if there is still no display then send the controller for repair.

RTC-FAIL – This can occur if the unit has been turned off for a prolonged period of time. Leave the unit on for ~30 seconds, then turn it off for ~30 seconds before turning it back on.

## **PUMP FAULTS:**

#### PUMP WILL NOT START:

The pump will only ever run for the purpose of automatic heating if the pool is below the temperature limit set in the heater.

If the pump does not operate then plug the pump into a power point and test operation, if the pump is OK and the heater has power and its time and function settings are correct, then the controller requires repair.

### PUMP WILL NOT STOP:

Turn off power to the controller and ensure the pump stops. If the pump continues to operate then unplug it from the power point and connect it to the 240Vac socket marked PUMP at the bottom of the controller.

#### **POOL NOT HEATING:**

Check and ensure that the Heater Interlock cable is connected to the plug properly and that the plug is pushed in.

# **Dontek Electronics Pty Ltd**

PO Box 239, Bayswater VIC 3153 Australia

Phone: +613 9762 8800 Email: sales@dontek.com.au







Check and make sure that the heater has power connected.

Check and ensure that the Heater Interlock cable is connected to the appropriate position inside the heater, <u>according to the heater manufacturer's instructions.</u>

PO Box 239, Bayswater VIC 3153 Australia
Phone: +613 9762 8800 Email: sales@dontek.com.au



