

## **TROUBLE SHOOTING AQUASMART 5CD**

### **NO POWER TO THE DISPLAY:**

Power point is faulty. Test power point with a known working appliance. If the power point is operational, check the controller in another power point and if there is still no display then send the controller for repair.

**RTC-FAIL** – This can occur if the unit has been turned off for a prolonged period of time, leave the unit on for ~30 seconds, then turn it off for ~30 seconds before turning it back on.

### **PIPE/ROOF SENSOR FAULTS:**

The following are error messages caused by pool or roof sensor faults;

#### **SENSOR DISCONNECTED OR OPEN CIRCUIT**

Sensor cable unplugged from controller, cable damaged, bad cable join, or sensor is damaged.

#### **SENSOR SHORT CIRCUIT OR REVERSED**

Sensor cable or cable join polarity is incorrect, or sensor is damaged. The positive side of the cable [grey coloured wire] should be wired to the righthand side of the plug, with the screws facing towards you and the sensor cable entry at the bottom of the plug. If the cable has been joined ensure no polarity reversal occurs.

#### **ISOLATING SENSOR FAULTS:**

**Swap the sensor locations. Put the pipe sensor in the roof socket and the roof sensor in the pipe socket.**

If the fault moves from pipe to roof or vice versa then it is likely that there is a sensor fault.

If the fault remains the same then the controller may need to be repaired.

### **PUMP FAULTS:**

Ensure the controller has working sensors; other-wise the pump will not operate.

### **SOLAR PUMP WILL NOT START:**

The pump will only ever run for the purpose of automatic heating if the pool is below the temperature limit and solar conditions can provide heating.

The pump may also run for a flush in winter-mode or for manual mode operation. If the pump does not operate then plug the pump into a power point and test operation, if the pump is OK then the controller requires repair.

If the controller is showing a “No Flow” error message, check to ensure chlorinator and filtration pump are plugged into the AUX socket and that the filtration pump is running. If a “No flow” error message is displayed and the filtration pump is running, reset the Pump Load Settings as described in INSTALLER SETUP.

### **PUMP WILL NOT STOP:**

## **Dontek Electronics Pty Ltd**

PO Box 239, Bayswater VIC 3153 Australia

Phone: +613 9762 8800 Email: sales@dontek.com.au

Turn off power to the controller and ensure the pump stops. If the pump continues to operate then unplug it from the power point and connect it to the 240Vac socket marked PUMP at the bottom of the controller.

#### **FILTRATION PUMP WILL NOT START:**

Ensure that the filtration pump is plugged into the Chlorinator properly and the Chlorinator is plugged into the Aquasmart5 CD AUX power socket properly and has power. Check filtration times set in the chlorinator. If it still won't start plug the filtration pump straight into a power point and turn on.

#### **FACTORY RESET:**

Hold down ENTER when power is off, hold down after powering up, releasing after 5 seconds.