

MODEL CC2 DIGITAL CONTROLLER

INSTALLATION INSTRUCTIONS

Controller Mounting

Find a suitable location to mount the control box. Ideally as with all pool equipment it should be installed out of direct weather and no closer than 3 meters from the water's edge. Lift up the two mounting tabs and use two appropriate screws to mount the control box to the wall, keeping in mind that the power cable is 1.8m long and should be plugged directly into a general power outlet, not into an extension lead.

Flow Switch

A Flow Switch should be fitted straight after the filter. It must be in a vertical position and plugged into the green plug socket beneath the controller. This will ensure that the pump only activates if the main pool pump is operating.

OPERATING INSTRUCTIONS

OPERATION

This controller will operate an in floor cleaner booster pump for a set period of time once water flow is detected, The SELECT button allows you to change from automatic operation to manual operation and choosing 'set run time' allows you to set the amount of hours the pump runs for once flow is detected.

The UP and DOWN buttons allow you to set the run time when 'set run time' is lit any changes will be stored once automatic mode is selected, if the UP or DOWN buttons are used while in automatic mode then it will alter the current or next run time the controller will then revert to the previously stored run time.

AUTO Mode – Automatic mode, when this light is lit the unit waits for water flow from the filtration pump to start, once flow is detected it will turn on the booster pump for the selected time.

MAN. OFF Mode – Manual OFF turns the pump OFF and prevents it from starting.

MAN. ON Mode - Manual ON turns the pump ON, but only if flow is present as shown by the flow light, if there is no flow the controller returns to automatic mode.

SET RUN TIME Mode – When this light is lit you can use the UP and DOWN buttons to increase or decrease the run time in half hour blocks (0.5) from 0.0 hours (disabled) to 5.0 hours, once you have selected the required time press SELECT to start automatic operation.

WARRANTY – CC2

This range of product is covered by a limited 2 year warranty against component failure or faulty workmanship from the date of installation.

A faulty unit should be returned in the first instance to the dealer from which the unit was purchased.

Damage to the unit due to misuse, power surges, lightning strikes or installation that is not in accordance with the manufacturer's instruction may void the warranty.

Warranty does not cover travel costs to or from installation site.

Return to supplier for repair

Customer Record. (To be retained by the customer)

Dealer/Installer Name _____

Model Number _____

Serial Number _____

Date Installed _____

For service assistance phone 1300 130 693

Dontek Electronics Pty Ltd
P.O. Box 239
Bayswater
Victoria 3153
www.dontek.com.au