

TROUBLE SHOOTING AQUASMART CC5 + TC

CLEANER BOOST PUMP CONTROLLER



NO POWER TO THE DISPLAY:

Power point is faulty. Test power point with a known working appliance. If the power point is operational, check the controller in another power point and if there is still no display then send the controller for repair.

RTC-FAIL – This can occur if the unit has been turned off for a prolonged period of time. Leave the unit on for ~30 seconds, then turn it off for ~30 seconds before turning it back on.

PUMP FAULTS:

Ensure the controller has a working flow switch, otherwise the pump will not operate.

BOOST PUMP WILL NOT START:

The pump will only ever run during the set filtration times. Check the Set Run Time to ensure that it isn't set to 0.

If the controller is showing a "No Flow" error message, check to ensure the chlorinator and filtration pump are running. If a "No flow" error message is displayed and the filtration pump is running, there may be an issue with the flow switch. This can be checked by unscrewing the flow switch wires and using a loop of wire in the flow switch plug at the base of the controller.

Dontek Electronics Pty Ltd

PO Box 239, Bayswater VIC 3153 Australia Phone: +613 9762 8800 Email: sales@dontek.com.au







If the pump does not operate then plug the pump into a power point and test operation. If the pump is OK then the controller requires repair.

PUMP WILL NOT STOP:

Turn off power to the controller and ensure the pump stops. If the pump continues to operate then unplug it from the power point and connect it to the 240Vac socket marked PUMP at the bottom of the controller.

FACTORY RESET:

Hold down ENTER when power is off, hold down after powering up, releasing after 5 seconds



